

PERTRONIC F100/120 IN-PANEL

CTU INSTALLATION

1. Installation

- a. Install CTU on to Pertronic F100/120 Fire Alarm Panel Masterboard using supplied stand-offs

2. Data Interface Connection

- a. Connect 5 wire loom (SGD Ribbon) on CTU board C2 connector (cable to the right)
- b. Connect to F100/120 Masterboard 5 wire loom connector (cable to the bottom)

3. Mains Power Supply (24v DC)

- a. Connect one end of supplied 2 wire cable in to DC input on CTU
- b. Connect to the 24v DC output on the F100/120 Masterboard

4. Backup CTU Battery (6v 1.3ah)

- a. Connect battery leads in to BATT input on CTU
- b. Attach to 6v 1.3ah battery placed behind F100/120 Masterboard batteries
- c. Note light will momentarily illuminate red when charging or running on battery

5. CTU Aerials

- a. Dual aerials required. Connect aerial flyleads/cables to both the Main and Diversity connectors on the CTU
 - i. Fixed Antenna – Install bulkheads at top of panel following ‘4G LTE Aerial Installation’ recommendations (approx. 150-200mm apart). Mount fixed aerials on top of panel vertically using 1x 200mm & 1x 300mm extension flyleads.
 - ii. Cabled Antenna - Run cabling through top of F100/120 panel and mount following ‘4G LTE Aerial Installation’ recommendations (approx. 150-200mm apart). Temporarily fix aerials to window ready for commission testing.

6. Commissioning Tests

- a. Comms light illuminates solid green to show CTU is connected to the cellular network
- b. Contact office on 03 341 0464 to test and commission the CTU and complete the connection to Fire & Emergency NZ.

PERTRONIC F100/120 IN-PANEL

